



Rev 020420

Manufactured in the USA



**sb tactical**  
[BRACE YOURSELF]®



For more information,  
visit [sb-tactical.com](http://sb-tactical.com)

## MPX PSB™, FS1913™ and TF1913™ INSTALLATION INSTRUCTIONS



**sb tactical**  
[BRACE YOURSELF]®

SB Tactical® strongly recommends a certified armorer or gunsmith install this part. If you choose to install the brace by yourself, please visit our website at [sb-tactical.com](http://sb-tactical.com) for video reference.

[sb-tactical.com](http://sb-tactical.com)



**PISTOL STABILIZING BRACE®**

## WARRANTY

SB Tactical warrants its products to be free from defects in materials and workmanship under normal use for (1) year from date of purchase. If you believe this product has any defects in materials or workmanship, cease use immediately and contact [support@sb-tactical.com](mailto:support@sb-tactical.com).

For complete information on compliance, warranty, and returns, visit [sb-tactical.com](http://sb-tactical.com)



**JOIN OUR EMAIL LIST**  
for the latest news on new products  
and special offers!

Visit  
[sb-tactical.com](http://sb-tactical.com)

# MPX PSB™, FS1913™ and TF1913™ INSTALLATION INSTRUCTIONS

After reviewing the following instructions, if you are not comfortable with the steps required, SB Tactical® strongly recommends that a certified gunsmith perform the installation.

The MPX PSB™ is 3-position adjustable and compatible with both the SIG MPX and SIG MCX.

1. Physically and visually check that the pistol is unloaded.
2. Fully extend brace in housing before installation.
3. Position housing on receiver M1913 rail so that brace rods align with receiver grooves.
4. Tighten locking screw in housing onto receiver M1913 rail.

## REQUIRED FOR INSTALLATION

- MPX PSB hardware kit (included)
- Allen wrench
- M1913 cross bolt

Housing



Locking Screw

## HELPFUL TIPS

- Compatible with both SIG MPX and SIG MCX
- To remove the brace, press the lever under the housing and slide the brace off
- 1/4" of vertical play is normal at full extension

After reviewing the following instructions, if you are not comfortable with the steps required, SB Tactical® strongly recommends that a certified gunsmith perform the installation.

The FS1913™ and TF1913™ are left side-folding brace assemblies, compatible with pistols utilizing an M1913 rail on the rear of the receiver (i.e. SIG MPX, SIG MCX, Rock River LAR-PDS, etc.).

1. Physically and visually check that the pistol is unloaded.
2. Lay the pistol on a flat surface and position the brace hinge on the desired slot on the left-side of the M1913 rail.
3. Place the hinge clamp on the right-side of the M1913 rail, aligning the slot in the clamp with the threaded hole in the hinge base.
4. Stabilize the brace assembly from underneath and thread the clamp bolt through the clamp and into the hinge base. (See photo to right)
5. Tighten the clamp bolt with the provided Allen wrench.

## REQUIRED FOR INSTALLATION

- FS1913 or TF1913 Hardware Kit (included)
- Allen wrench
- clamp bolt
- hinge clamp



## HELPFUL TIPS

To unlock and fold the FS1913 or TF1913, place your thumb on top of the receiver with your fingers under the strut. Press down with your thumb while pulling up with your fingers to release the hinge.



For more detailed instruction, view Installation Videos at [sb-tactical.com](http://sb-tactical.com)